

87 FUZZ



MANUAL

Introducing the 87 Series FUZZ from Demonic Machines, a pedal designed to deliver a mind-blowing fuzz eXperience at an affordable price. Our relentless pursuit of sonic eXcellence led us to create a pedal that defies conventional naming conventions, hence we aptly named it “FUZZ.”

CONTROLS:

The Volume Knob:

- To increase the volume, turn the knob clockwise.
- To decrease the volume, turn the knob counter-clockwise.

Enjoy eXploring the sonic possibilities of the 87 Series FUZZ and prepare for a face-melting fuzz eXperience like no other!

SWITCHING

This pedal features DPDT true relay bypass switching.

POWER REQUIREMENTS

This machine takes a standard 9 volt DC power supply with a 2.1mm negative center barrel. We always recommend pedal-specific, transformer-isolated wall-wart power

supplies or multiple isolated-output supplies.


Pedals will make extra noise if there is ripple or unclean power. Switching-type power supplies, daisy chains and nonpedal specific power supplies do not filter dirty power as well and let through unwanted noise. DO NOT RUN AT HIGHER VOLTAGES!

Current draw: <60ma

WARRANTY

This machine has a limited lifetime warranty. If it breaks, we will fix it. Should you encounter any issues, please email info@demonicmachines.com

CHECK US OUT ONLINE!



<https://demonicmachines.com/>

Demonic Machines kill
fascists.