

Amp Chiller attenuator



STEP 1: Connect the Amp Chiller to your amp's effects loop. IMPORTANT: Make sure to place the Amp Chiller in the effects loop and not between your amp and your speaker.

STEP 2: Increase the volume on your amp until you achieve the desired distortion effect that you enjoy.


STEP 3: Utilize the Amp Chiller to adjust and lower the volume of your amp while preserving the pre-amp breakup characteristics.

By following these steps, you can effectively use the Amp Chiller by Demonic Machines to control the volume of your amp without sacrificing the desirable preamp distortion.

WARRANTY

This machine has a limited lifetime warranty. If it breaks, we will fix it. Should you encounter any issues, please email info@demonicmachines.com

CHECK US OUT ONLINE!



<https://demonicmachines.com/>

Demonic Machines kill fascists.